

TWO-WAY LED AUTOMATIC TRANSMISSION
REMOTE STARTER

User Guide

WARNING



It is the responsibility of the vehicle operator to ensure their vehicle is parked in a safe and responsible manner.

1. When leaving the vehicle, it is the user's responsibility to ensure that the gearshift lever is in "**Park**" in order to avoid accidents upon remote starting.
2. It is the user's responsibility to ensure that the remote starter is disabled or put into valet mode before servicing.

FCC USER NOTICE (U.S.A.):

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Table of Contents



Introduction	2	Ignition-Controlled Door Locks.....	7
Using the Remote Control	3	Ignition Re-lock.....	7
Vehicle Presets	3	Secure Lock.....	8
Heater & Heated Seat	3	Remote Trunk Release	8
Windshield Wipers & Radio & Headlights ..	3	The Starter Kill and the Anti-grind Feature.	8
Arming the Starter Kill	4	Safe Start.....	8
Remote-Starting Your Vehicle	4	Valet Modes.....	8
Remote-starting.....	4	Valet Mode Using the Valet Switch (if installed)	8
Driving Off	4	"Home Valet™" Mode.....	8
Remote Starter Features	4	Turbo Mode	9
Idle Mode.....	4	Engine Run Time.....	9
Valet Modes	5	Flashing LED.....	9
Ignition Valet.....	5	Multi-car Operation.....	9
Remote Valet Mode	5	Multi-Level Features (default state)....	10
Panic Mode	5	Vehicle Status Request	11
Quick Lockout™.....	6	Status Request When the Engine IS NOT Running	11
Cold Weather Mode	6	Status Request When the Engine is Running	12
Extended Run Time	6	Troubleshooting Transmitting Range	12
Feature Confirmation Chart	7	Diagnostics – Parking Light Flash Table	13
Advanced Features: Installation-programmable Options	7		
Remote Door Locks	7		
Priority Door Access.....	7		

Introduction

This is a state-of-the-art remote starter system. The system is packed with advanced features such as priority access to the driver's door (commodity features) and the safe start children safety feature. With many an advanced function, this product will satisfy any one your expectations from high-end commodity and security systems, without neglecting any standard feature commonly offered by entry-level starters.

Using the Remote Control

Your remote starter is equipped with a 5-button multi-channel remote control. It can operate two independent vehicles equipped with a remote starter (see **Multi-car operation** section on page 9). The functions of the transmitter are as follows:



Picture serves as example only.

For certain vehicles:

- Pressing and holding the **LOCK** button for more than 3 seconds will lock all doors and will send a constant pulse as long as the **LOCK** button is held down (maximum of 15 seconds). This constant pulse can be configured to activate certain functionalities such as rolling up the windows – **Please refer to your installer to see if your vehicle is compatible with this option.**
- Pressing and holding the **UNLOCK** button for more than 3 seconds will unlock all doors and will send a constant pulse as long as the **UNLOCK** button is held down (maximum of 15 seconds). This constant pulse can be configured to activate certain functionalities such as rolling down the windows – **Please refer to your installer to see if your vehicle is compatible with this option.**

Vehicle Presets

Heater & Heated Seat

When leaving the vehicle it is recommended to preset the accessory controls in preparation for the next remote start. Settings for the blower motor (fan), front and rear, as well as heated seats (if equipped) should not be left on **HIGH**. It is recommended to leave the settings on **LOW** or **MEDIUM** instead.

Windshield Wipers & Radio & Headlights

Certain vehicles require the radio and / or windshield wiper and / or headlight circuits to become energized while running under remote start. When leaving the vehicle you must ensure that the windshield wiper and headlight switches are **OFF**. Leaving the headlight switch **ON** on certain types of vehicles could cause them to remain **ON** even after remote starter shut down, resulting in a dead battery.

Arming the Starter Kill

The starter kill (if installed) can be configured by the installer so as to arm automatically (passive mode) or not to arm automatically (active mode).

- To **disarm** the starter kill, press the **UNLOCK** button on the transmitter.
The parking lights will flash twice.
If remote door locks are installed, this will also unlock the doors.
- To **arm** the Starter Kill, press the **LOCK** button on the transmitter.
The parking lights will flash once.
If remote door locks are installed, this will also lock the doors.
- In **passive mode**, the starter kill will automatically arm if the ignition key is not inserted into the ignition switch within 1 or 3 minutes after unlocking (the key sense feature must be installed).

Remote-Starting Your Vehicle

Remote-starting

Press the **START/STOP** button for approx. 1 second. The parking lights will come **ON** to inform you that the remote starter has received your signal. Approximately 5 seconds later, the engine will start. The parking lights will remain **ON** during the pre-programmed run time of the engine.

If the vehicle does not start at the first attempt, the system will shut down, wait a few seconds and try to start the engine again. There will be 3 start attempts before the system gives up.

Driving Off

With the vehicle running under remote control, press the **UNLOCK** button to disarm and unlock the doors. Enter the vehicle and do the following:

Turn the ignition key to the **IGNITION ON (RUN)** position. (**Do not turn the key** to the **CRANK** position while the engine is running. This would cause the starter motor to re-engage.)

Press the brake pedal to disengage the remote starter unit.

You are now ready to drive off.

Remote Starter Features

Idle Mode

Convenience feature: Idle mode allows you to keep the engine running and the doors locked while you stop, for example, at a convenience store or for a short delivery.

This feature allows you to let the remote starter take over control of the vehicle (i.e. no key in the ignition switch) while the engine is running. For example, if you stop for a delivery or at a convenience store, lock your vehicle and leave it running for the length of a run cycle while you are away.

To leave the vehicle in idle mode:

1. With the engine running, press the **LOCK** or **UNLOCK** button (to unlock the doors) or the **START/STOP** button on the remote control until the parking lights come on.
2. Remove the key and exit the vehicle. The engine will go on running.
3. Lock the doors if needed.

The engine will go on running until the user re-enters the vehicle or until the expiration of the engine run time.

Caution!!! Do not leave children or pets unattended in a vehicle standing in Idle Mode.

Valet Modes

When your vehicle is in valet mode, the remote starter functionalities are disabled. If the vehicle needs to be serviced, or if you park it indoors, the valet mode will prevent the engine from being remote-started accidentally.

Ignition Valet

This feature will allow you to remotely put your system into valet mode by using the ignition key instead of the valet button as above. Ignition valet can be used without a valet button installed.

To put the system i n t o valet mode:

Insert the ignition key into the ignition switch. Within 10 sec., turn the key 5 times successively into the **IGNITION ON / RUN** and **OFF** positions.

The parking lights will flash three times to indicate that the vehicle is now in valet mode. The L.E.D. will come **ON** solid.

To take the system o u t o f valet mode:

Insert the ignition key into the ignition switch. Within 10 sec., turn the key 5 times successively into the **IGNITION ON / RUN** and **OFF** positions.

The parking lights will flash twice to indicate that the vehicle is now out of valet mode. The L.E.D. will go out.

Note: With the ignition valet activated, the remote starter functions will be disabled.

Remote Valet Mode

This feature will allow you to remotely put your system into valet mode by using the transmitter instead of the valet button as above.

Getting into valet mode

- Hold the **UNLOCK** and **START/STOP** buttons simultaneously for 3 second.
- **The parking lights will flash 3 times.**

The LED will remain on solid.

Getting out of valet mode

- Hold the **UNLOCK** and **START/STOP** buttons simultaneously for 3 second.
- **The parking lights will flash 2 times.**

The LED will turn off.

Note: With the remote valet activated, the remote starter functions will be disabled.

Panic Mode

Note: Panic mode can only be activated if the horn has been adequately configured by your installer.

In an emergency situation, you can activate panic mode by pressing and holding the **SHIFT** button for 3 seconds. If the vehicle is under a remote start, you can shutdown the engine, stop the horn and lock your doors by pressing the **LOCK** button:

If the car is not running, you can stop the horn by pressing the **LOCK** or **UNLOCK** buttons but it will not lock or unlock the doors.

Furthermore, the panic mode can be stop by activating one of the following three (3) features:

- a) Remote valet (pressing **UNLOCK** and **START/STOP** for 3 seconds)
- b) Ignition valet (turning the key inside the ignition switch from **OFF** to **ON** 5 times in a row)
- c) By pressing the valet switch (if included).

Panic Mode will automatically shut down after 25 sec.

Quick Lockout™

(Also called **secure panic.**) For fast protection in emergency situations, the system will **LOCK** all doors when you **press the brake pedal while you hear the sound signal.** (**Quick lockout** is only available when **panic mode** has been set off.)

Cold Weather Mode

When cold weather mode is active, the engine starts every 2 hours and runs for 3 minutes (or for 8 or 20 minutes with diesel engines). Cold weather mode automatically ends after 24 hours.

To enter Cold Weather Mode:

- Press the **SHIFT** button and then the **START/STOP for 3 seconds.**
- There will be two (2) beeps and the parking lights will flash three (3) times.

To exit Cold Weather Mode, do any one of the following actions:

- Open the hood.
- Start the engine by remote.
- Turn the ignition key to the **IGNITION ON (RUN)** position.
- Press the **SHIFT** button and then the **START/STOP** button for three seconds.

There will be one (1) beep and the parking lights will flash once.

To verify whether the system is in cold weather mode:

Press and release the brake pedal:

If the vehicle is in cold weather mode, the parking lights will stay on while the pedal is pressed.

Extended Run Time

While the vehicle is running under a remote start, **pressing and holding the START/STOP button for more than 3 seconds** will reset the run time counter to zero and restart the run time cycle from the beginning. There will be one beep—a pause—three more beeps; the parking lights will flash three times and the horn (if configured) will honk once. **The extended run time procedure can only be carried out once per remote start.**

To stop the vehicle, at any moment, simply press the **START/STOP** button.

Example: If your remote car starter is programmed for a run time of 3 minutes and your vehicle has been running for 3 minutes already, pressing the **START/STOP** button will reset the counter to zero and allow the engine to run for another cycle (in this case, 3 minutes).

Feature Confirmation Chart

A visual and audible confirmation is emitted each time a command is sent. The following chart indicates the confirmation sequences:

Feature	LED #1	LED #2	LED #3	LED #4	Beep(s)
Lock	3 flashes	X	X	X	1
Unlock	X	3 flashes	X	X	2
Trunk	X	X	3 flashes	X	1
LED ON/OFF	3 flashes	3 flashes	X	X	1
Start	X	X	X	3 flashes	1
Running	X	X	X	3 flashes	3
Stop	X	X	X	3 flashes	2
Entering Cold Weather Mode	X	X	X	3 flashes	2
Exiting Cold Weather Mode	X	X	X	3 flashes	1
Home Valet	3 flashes	X	X	3 flashes	2
Valet Mode	3 flashes	X	X	3 flashes	1
Exit ValetMode	X	3 flashes	X	3 flashes	1

Advanced Features: Installation-programmable Options

The remote starter was designed with flexibility and OEM integration in mind. With its programmable options, this unit can single-handedly control nearly any electrical system in your vehicle.

Caution: The programming of your system should be left to a professional. Changing any one of the settings may affect the operation of your remote starter.

Remote Door Locks

If your remote starter was installed with the remote door locks option, you will have the convenience of remote keyless entry. See section **Arming the Starter Kill**, on page 4, for further instructions on remote door locking and unlocking.

Priority Door Access

If the remote door locks option is installed on your vehicle, this safety feature allows you unlock solely the driver's door with a single press of the **UNLOCK** button on the transmitter; upon a second press of the **UNLOCK** button, all the other doors will unlock.

Ignition-Controlled Door Locks

This is an added security feature. If your remote starter was installed with the ignition-controlled door locks option, the doors will automatically be locked as soon as the ignition key is turned to the **IGNITION ON (RUN)** position while the brakes are pressed. When the key is turned to the **OFF** position, the doors will automatically be unlocked.

Ignition Re-lock

On remote starters of this series, when ignition-controlled door locks are enabled and the ignition key is in the **IGNITION ON (RUN)** position, should any door be unlocked and opened, all doors will be relocked next time the brake pedal is pressed.

Secure Lock

Before it can remote-start your vehicle, the remote starter must first disarm the factory security system. The secure lock feature may be required on certain vehicle models with factory security systems that automatically unlock the doors when the security system is disarmed.

To keep your vehicle protected when the factory security system is disarmed for a remote start, secure lock will relock your doors as soon as the vehicle has started. Once the engine run cycle ends, secure lock will rearm your factory security system.

Remote Trunk Release

If your system was installed with the remote trunk release option, you can open your trunk by pressing the **TRUNK** button. There will be one beep and LED #3 will flash 3 times.

The Starter Kill and the Anti-grind Feature

With this added security feature, the system will prevent your vehicle from starting with the ignition key when the starter kill is armed. If your remote starter was installed with the starter kill option, one will not be able to start your vehicle with the key unless the system has been unlocked and disarmed first, or put into valet mode.

Note: If the starter kill is installed, your vehicle will benefit from a protection against starter motor damage that could occur after remote-starting the engine should the user, by force of habit, turn the ignition key to the **CRANK** position.

Safe Start

If this feature is enabled, the user must press the **START/STOP** button 2 times within 3 seconds to remote-start the vehicle. This will eliminate accidental remote starts, e.g. when children are playing with the transmitter.

If **swap start mode** is selected, to remote-start your vehicle, press the **SHIFT** button and then the **LOCK** button. The **AUX 2** output can be activated by pressing the **START/STOP** button.

Valet Modes

Valet Mode Using the Valet Switch (if installed)

To put the system i n t o valet mode:

1. Turn the ignition key to the **IGNITION ON (RUN)** position.
2. Within 3 sec., press the valet button.

The parking lights will flash three times to indicate that the vehicle is now in valet mode.

3. Turn the ignition key to the **OFF** position.

The L.E.D. will come **ON** solid.

To take the system o u t o f valet mode:

1. Turn the ignition key to the **IGNITION ON (RUN)** position.
2. Within 3 sec., press and release the valet button.

The parking lights will flash twice to indicate that the vehicle is now out of valet mode.

3. Turn the ignition key to the **OFF** position.

The L.E.D. will go out.

Note: Once valet mode is activated, the remote starter functions will be disabled.

“Home Valet™” Mode

If configured at installation, this feature will remotely set the vehicle to a no-remote-start mode: if the vehicle is parked indoors there is no danger of it starting accidentally by remote control.

Note: Once the home valet mode is activated, the vehicle will not start by remote.

To take the system i n t o home valet mode:

- Press the **LOCK** or **UNLOCK** button.

- Within 3 seconds, press the **LOCK** and **START/STOP** buttons simultaneously until the parking lights go **out**

To take the system out of home valet mode:

- Turn the ignition key to the **IGNITION ON (RUN)** position.

The system will warn you if someone attempts to start your vehicle while it stands in home valet mode. The parking lights will:

- 1- Turn **ON** then **OFF**; then
- 2- Flash **twice**, pause; then
- 3- Flash **twice** again.

Turbo Mode

If turbo mode is configured at installation, it will allow a turbocharger to idle down after the user leaves the vehicle: the unit will take over the vehicle and keep it running for 60 seconds (or until it is shut down by remote control), then shut down the engine.

Proceed as follows to set the system to Turbo Mode:

1. With the engine already running, press the **LOCK** button on the transmitter until the parking lights come **ON**.
2. Remove the ignition key from the ignition switch. The engine will go on running.
3. Exit the vehicle and close the door.
4. Press the **TRUNK** button to lock the doors; the engine will shut down after 60 seconds of Turbo Mode.

Engine Run Time

If you have a gas engine, your remote starter can be programmed to run the engine for **3**, **15**, or **25** minutes (15 minutes by default). If you have a diesel engine, the remote starter can be programmed to run the engine for **8**, **20**, or **30** minutes (20 minutes default).

Flashing LED

The user may decide to turn on or off LED flashing at any moment. To do so, simultaneously press and hold the **LOCK** and **UNLOCK** buttons on the transmitter. There will be an initial beep. Keep holding the buttons pressed until you hear another beep. At that point release the buttons. The LED will toggle to its next state –i.e.: ON/OFF:

There are three programmable options regarding the flashing LED:

- i. The LED flashes once the starter kill is activated (passive or active arming) and will turn itself off once the user turns the key to the **IGNITION ON** position.
- ii. The LED is totally disabled and will not flash –it will turn on solid, however, when in valet mode.
- iii. The LED will flash once the starter kill is activated but requires pressing the **UNLOCK** button to turn itself off. Failure to press the **UNLOCK** button will make the LED flash even if the key is in the **IGNITION ON** position.

Multi-car Operation

This option allows the owner of two vehicles, both equipped with the same remote starter model, to control both systems with a single remote control. To control the second vehicle:

Press TRUNK + LOCK buttons simultaneously:.....	LOCK
Press TRUNK + UNLOCK simultaneously:.....	UNLOCK
Press TRUNK + START/STOP simultaneously:.....	START
Press TRUNK + START/STOP simultaneously:.....	STOP
Press SHIFT > SHIFT > TRUNK:	TRUNK

or

Press SHIFT > SHIFT > LOCK:	LOCK
Press SHIFT > SHIFT > UNLOCK:.....	UNLOCK
Press SHIFT > SHIFT > START/STOP:.....	START
Press SHIFT > SHIFT > START/STOP:.....	STOP
Press SHIFT > SHIFT > TRUNK:	TRUNK

Note: If the multi-level features have been modified from their default state by your installer, the **SHIFT** button may have to be pressed once, twice or three times, according to the option you chose.

Multi-Level Features (default state)

The multi-level features allow you to access different features of your vehicle or of a second car by pressing the shift button once, twice or three times. By default, the multi-level features are programmed as follows:

Basic Features (press the SHIFT button 1X)

SHIFT >	LOCK:	aux 2
SHIFT >	TRUNK:	status request
SHIFT >	START/STOP.....	cold weather

Multi-Car Operation (press the SHIFT button 2X)

SHIFT >	SHIFT >	LOCK:	2 nd car lock
SHIFT >	SHIFT >	UNLOCK:	2 nd car unlock
SHIFT >	SHIFT >	START/STOP:	2 nd car start/stop
SHIFT >	SHIFT >	TRUNK:	2 nd car trunk

Customized Features (press the SHIFT button 3X)

(May not be applicable for certain vehicles)

Your installer can add customized features such as turning on the radio, opening sliding doors, etc.

SHIFT >	SHIFT >	SHIFT >	LOCK:	customized feature 1
SHIFT >	SHIFT >	SHIFT >	UNLOCK:	customized feature 2
SHIFT >	SHIFT >	SHIFT >	TRUNK:	customized feature 3
SHIFT >	SHIFT >	SHIFT >	START/STOP:	customized feature 4

Your installer can customize the system as to personalize these multi-level features in an order that best suits you. Your options are:

Option 1:	
Level 1 (requires pressing the SHIFT button 1X)	→ Multi car operation
Level 2 (requires pressing the SHIFT button 2X)	→ Basic features
Level 3 (requires pressing the SHIFT button 3X)	→ Customized features
Option 2:	
Level 1 (requires pressing the SHIFT button 1X)	→ Basic features
Level 2 (requires pressing the SHIFT button 2X)	→ Multi car operation
Level 3 (requires pressing the SHIFT button 3X)	→ Customized features
Option 3:	

- Level 1 (requires pressing the **SHIFT** button 1X) → Customized features
- Level 2 (requires pressing the **SHIFT** button 2X) → Multi car operation
- Level 3 (requires pressing the **SHIFT** button 3X) → Basic features

Option 4:

- Level 1 (requires pressing the **SHIFT** button 1X) → Basic features
- Level 2 (requires pressing the **SHIFT** button 2X) → Customized features
- Level 3 (requires pressing the **SHIFT** button 3X) → Multi car operation

Example: If the multi-level features have been modified from their default state to option 3, the setup would be as follows:

For “**Basic features**”:

- To access the **aux.2** feature, the user needs to press on the **SHIFT** button **three (3)** times followed by the **LOCK** button.
- To access the **status request** feature, the user needs to press on the **SHIFT** button **three (3)** times followed by the **TRUNK** button.
- To access **cold weather mode**, the user needs to press on the **SHIFT** button **three (3)** times followed by the **START/STOP** button.

Vehicle Status Request

The status request feature allows the user to see the status of the vehicle —i.e.: if the doors are locked or unlocked or if the vehicle is in cold weather mode, home valet mode, in valet mode or how much time is left in the run time cycle. The following charts (Tables 1 and 2) indicate the confirmation sequences.

To retrieve the vehicle status:

Press and release the **SHIFT** button then press and release the **TRUNK** button (there will be a beep). The transmitter will then flash the corresponding sequence of LEDs depending on the vehicle’s status.

- **If the engine is NOT running**, refer to Table 1.
- **If the engine IS running under a remote start**, refer to Table 2 (if the doors are locked) or refer to Table 3 (if the doors are unlocked).

The status request feature is a two-step procedure:

- The first sequence of flashes denotes if the vehicle’s doors are locked or unlocked.
- The second sequence of flashes (if applicable) denotes if the vehicle is *Cold weather mode*, *Home valet mode*, or *Valet mode*.
- If there is no second sequence transmission, that the vehicle is not in any of the three (3) mentioned features (*Cold weather mode*, *Home valet mode* or *Valet mode*).

Status Request When the Engine IS NOT Running

STATUS	SEQUENCE	LED #1	LED #2	LED #3	LED #4	Beep(s)
Lock		3 flashes	X	X	X	1
Unlock		X	3 flashes	X	X	2
Cold Weather	1 st sequence if locked	3 flashes	X	X	X	2
	1 st sequence if unlocked	X	3 flashes	X	X	2
	2 nd sequence	X	X	X	1 second	X
Home Valet	1 st sequence if locked	3 flashes	X	X	X	2

STATUS	SEQUENCE	LED #1	LED #2	LED #3	LED #4	Beep(s)
	1 st sequence if unlocked	X	3 flashes	X	X	2
	2 nd sequence	1 second	X	X	1 second	X
Valet Mode	1 st sequence if locked	3 flashes	X	X	X	1
	1 st sequence if unlocked	X	3 flashes	X	X	1
	2 nd sequence	1 second	X	X	1 second	X

Table 1

Status Request When the Engine is Running

When the vehicle doors are locked:

The LED # 1 will flash 3 times to denote that the vehicle's doors are locked.

When the vehicle doors are unlocked:

The LED # 2 will flash 3 times to denote that the vehicle's doors are unlocked.

RUN TIME	Beep(s)	LED #1	LED #2	LED #3	LED #4
If there is more than 3/4 of run time cycle	3	ON for 1-sec	ON for 1-sec	ON for 1-sec	ON for 1-sec
If there is more than half of run time cycle	3	ON for 1-sec	ON for 1-sec	ON for 1-sec	X
If there is more than 1/4 of run time cycle	3	ON for 1-sec	ON for 1-sec	X	X
If there is less than 1/4 of run time cycle	3	ON for 1-sec	X	X	X

Table 2

Troubleshooting Transmitting Range

Many factors may affect the operating range of the transmitter. Some of these are:

- The condition of the battery in the transmitter.
- The operating environment (for example: downtown radio-frequency noise, airports, cellular phone towers...)
- Metal: any type of metal will affect operating range. This includes the metal in the car.
- The shape of the vehicle can affect range as well; vans in general have an especially poor range.
- The shape of the roof and A-pillars brings about considerable radio-frequency deflection (in this case the signal from the remote control). As a result, the direction in which the vehicle is facing in relation to the remote control can affect the range. Straight on – standing in front of the vehicle – generally gives you the greatest range; the second best performance is from the back. Using the remote control from either side of the vehicle will usually give the lowest range.
- The range will be significantly lower in a crowded parking lot than in open space.
- Always hold the transmitter high, approximately at shoulder height. Holding the transmitter against your chin will also increase your range: your head acts as an antenna.
- The operating range will be somewhat lower on vehicles equipped with an aftermarket or factory alarm.

Diagnostics – Parking Light Flash Table

Flashes	Description
1	<ul style="list-style-type: none"> Doors locked, starter kill armed End of run time TRUNK button pressed Start signal received by the module Cold weather mode cancelled
2	<ul style="list-style-type: none"> Doors unlocked, starter kill disarmed Run time cancelled Remote start attempt cancelled by remote Exiting remote valet Exiting ignition valet
3	<ul style="list-style-type: none"> Entering cold weather mode. Entering extended run time. Entering remote valet Entering ignition valet
4	<ul style="list-style-type: none"> +12 V where detected on the brake line and cranking was cancelled. Entering tach-programming mode
5	<ul style="list-style-type: none"> New transmitter programmed. Tach programmed.
6	<ul style="list-style-type: none"> A remote start was attempted while a tach or a vacuum signal was detected before cranking.
8	<ul style="list-style-type: none"> Unit reset: occurs when the unit is reset to the factory defaults.
10	<ul style="list-style-type: none"> The hood switch line went to ground during cranking or run time.
1 – pause – 2	<ul style="list-style-type: none"> There was an attempt to start the vehicle while the module was in valet mode.
ON solid	<ul style="list-style-type: none"> Cold weather mode: the brake pedal is being held down.
2 – pause – 2	<ul style="list-style-type: none"> There was an attempt to start the vehicle while the module was in home valet mode.
ON 2 sec.	<ul style="list-style-type: none"> The hood is up and the hood switch line went to ground. This is step one of the programming centre procedure.
ON 3 sec.	<ul style="list-style-type: none"> First press of the START button under safe start.
ON 4 sec.	<ul style="list-style-type: none"> Locking or unlocking a door (with door pulses configured to 4 sec.)
ON 25 sec.	<ul style="list-style-type: none"> The hood pin-switch has been pressed twice: the unit went into step 1 of the programming centre procedure, and no transmitter activity was detected for 20 seconds. Or the unit went into step 1 of the transmitter programming procedure and no activity was detected for a few seconds. The unit has exited the transmitter programming procedure.
Irregular	<ul style="list-style-type: none"> If the unit gives irregular signals (1 to 10 flashes followed by a pause, followed by further flashes), the system is playing back start failure codes. This occurs when the hood pin-switch is pressed three times
Constant flashes up to 25 sec.	<ul style="list-style-type: none"> Panic mode is triggered.