



PRIMESTART 450

**Keyless Entry &
Remote Engine Starter System**

Owner's Manual

PrimeStart 450 Owner's Manual

WARNING

- !** Always exercise caution and common sense when operating your PrimeStart system.
- !** This product is intended for vehicles with fuel-injection and automatic transmissions only. NEVER attempt to remote start a vehicle with a manual (stick shift) transmission. Serious injury may occur with improper use.
- !** NEVER attempt to remote start the engine while anyone (including pets) is in the vehicle.
- !** NEVER attempt to remote start the engine while the vehicle is in an enclosed area without sufficient ventilation.
- !** NEVER attempt to remote start the engine while the keys are in the ignition.
- !** Always be sure the gearshift selector is in "Park" and the emergency brake is on before attempting to remote start the vehicle.
- !** Keep your PrimeStart remote controls out of the reach of children.
- !** Whenever the vehicle is being serviced or valet parked, place the system in Protected Valet Mode to prevent accidental or unauthorized remote starting. See "Protected Valet Mode" on page 9.

Table of Contents

PrimeStart 450	2
Lifetime Warranty	2
Remote Controls	2
Stealth Coding™ Technology	3
Electronic Scan Prevention (ESP)	3
Instant Remote Control Code Deletion	3
One-Step Remote Control Code Learning	3
Valet Switch	3
Operating Your PrimeStart	4
Remote-Controlled Door Lock/Unlock	4
Two-Stage Unlock Capability	4
User-Programmable Ignition-Controlled Door Lock/Unlock	4
User-Programmable RPM Door Lock	4
Remote Panic with Safety Locks™ (capability)	5
User-Programmable Starter Disable	5
User-Programmable Passive Starter Disable	5
Interior Light Illumination	5
Remote-Controlled Trunk Release Capability	6
Remote-Controlled Accessory Output	6
Remote Engine Start - Safety and Counter-Theft	6
Remote Engine Start - Operation	7
User-Programmable Temperature-Controlled Starting	8
Pit Stop Mode	8
Protected Valet Mode	9
User-Programmable Features	10
Programming Table for System Features	11
Programming Table for Remote Controls	12

PrimeStart 450

Congratulations! You have just purchased the **PrimeStart 450**, a keyless entry and remote engine starter system manufactured by Prime Security. You are about to experience the convenience and luxury of being able to start your vehicle engine from the comfort of your home, office, department store or other remote location.

To benefit fully from the capabilities of your PrimeStart system, we encourage you to read the Owner's Manual thoroughly **before** using the system. If you should have any problems or questions regarding your PrimeStart system, consult the dealer from whom you purchased this product. To locate an authorized Prime dealer, contact Prime Security directly at 1-800-253-0334 (toll-free within the U.S.) or 1-847-215-2233.

Lifetime Warranty

Prime Security guarantees the operation of your PrimeStart control unit and remote controls for as long as you own your car. (Please refer to your Lifetime Limited Warranty Card for complete information.) Make sure that you receive your warranty card from your dealer, complete the required information and mail the registration portion to Prime Security. You should retain the top portion of the warranty card for your records.

Remote Controls

Included with your PrimeStart system are two AviGlo™ 4-button/9-channel remote controls. Once exposed to light, the AviGlo™ remote control buttons will glow, making the buttons visible in the dark.

The remote control (remote) is a miniature transmitter powered by a small +12 volt battery. The RangeMaster™ super-heterodyne receiver (installed in your vehicle) allows your remote to command your system from up to ¼ mile away. Obstructions, electrical or radio interference, weather conditions, window tint or a weak battery can reduce this range. Your remote is the key to your PrimeStart system and can be used lock and unlock your doors, "pop" your trunk, start your engine and control optional accessories.

The PrimeStart system can accept up to four Prime remote controls. Additional remote controls and remote control batteries can be purchased from any authorized Prime Security dealer, or by calling Prime Security toll-free at 1-800-253-0334 (within the U.S.) or 1-847-215-2233.

Stealth Coding™ Technology

Stealth Coding™ technology offers the most advanced protection available against "code-grabbing" devices which thieves may use to record the digital code transmitted by your remote control. When you leave the area, thieves can then play back the code to unlock the doors and deactivate your system. But Prime Security's remote controls with Stealth Coding™ randomly change the code every time you use them, and your system will not respond if any code is retransmitted. This technology makes code-grabbing devices useless.

Electronic Scan Prevention (ESP)

Your PrimeStart system also includes ESP, which blocks electronic scanner codes to prevent unauthorized operation of your system.

Instant Remote Control Code Deletion

In the event of a lost or stolen remote control, all remote controls can be erased from the system's memory to prevent unauthorized system operation. (See the "Programming Table for Remote Controls" on page 12).

One-Step Remote Control Code Learning

The PrimeStart system allows you to add new remote controls in one step. (See the "Programming Table for Remote Controls" on page 12).

Valet Switch

The valet switch is a small hidden toggle switch which allows you to control all of the system's programmable features. (See the "User-Programmable Features" on page 10). This switch can **only** be controlled with the use of your ignition key.

NOTE: Be sure to have your dealer show you where the valet switch is located.

Operating Your PrimeStart

Remote-Controlled Door Lock/Unlock

To Lock the Doors:

Press the remote control LOCK button for 1-2 seconds. The doors will lock, the parking lights will flash twice and the dash mounted LED will flash slowly. If the Remote Lock Starter Disable feature was programmed ON, the vehicle starter motor will be disabled. (See the "Programming Table for System Features" on page 11.)

To Unlock the Doors:

Press the remote control UNLOCK button for 1-2 seconds. The doors will unlock. The interior lights will turn on for 30 seconds or until the ignition key is turned on. The parking lights will flash once and the dash mounted LED will turn off. If the Remote Lock Starter Disable feature was programmed ON, it will disengage allowing you to start the vehicle engine.

Two-Stage Unlock Capability

If the optional Two-Stage Unlock feature was installed, press the UNLOCK button for 1-2 seconds and only the driver door will unlock. Within 3 seconds, press the UNLOCK button again and the passenger doors will unlock (may require an optional relay).

User-Programmable Ignition-Controlled Door Lock/Unlock

For the ultimate in security and convenience, the PrimeStart can be programmed to automatically lock your doors when the ignition key is turned on or the engine is started, and will unlock when the ignition key is turned off. This feature can be programmed ON or OFF. (See the "Programming Table for System Features" on page 11.)

User-Programmable RPM Door Lock

The system can be programmed to automatically lock the doors when the engine reaches the factory preset RPM level. (See the "Programming Table for System Features" on page 11).

When you begin driving, your vehicle doors will automatically lock. When you turn the ignition key off, the doors will automatically unlock.

NOTE: Ignition-Controlled Door Lock feature must be programmed OFF.

Remote Panic with Safety Locks™ (capability)

In a threatening situation, you can activate Remote Panic with Safety Locks™. When activated, the siren/horn will sound and the parking lights will flash. If you are inside your vehicle and the ignition key is "ON," the doors will lock. If you are outside the vehicle with the ignition key "OFF," the doors will unlock allowing you to move to safety. (Requires the addition of a siren or interfacing with your vehicle horn.)

To Activate:

1. Press the remote control LOCK button for 3-4 seconds.
2. The siren/horn will sound and the parking lights will flash.
3. If the ignition key is "OFF," the doors will unlock. If the ignition key is "ON," the doors will lock.

To Deactivate:

1. Press the remote control LOCK button for 1-2 seconds.
2. The siren/horn will shut off and the parking lights will stop flashing.

User-Programmable Starter Disable

The PrimeStart can be programmed to electronically disable the vehicle starter every time the doors are remote locked. (See the "Programming Table for System Features" on page 11).

User-Programmable Passive Starter Disable

Your PrimeStart system can be programmed to automatically disable the vehicle starter whenever you exit the vehicle. (See the "Programming Table for System Features" on page 11.)

To Activate:

1. Turn the ignition key "OFF." The LED will begin to flash rapidly.
2. After 30 seconds, the LED will flash slowly and the starter will be disabled.

To Deactivate:

1. Press the remote UNLOCK button for 1-2 seconds.

Interior Light Illumination

When you remote unlock the doors, PrimeStart will turn on the vehicle interior light(s) for 30 seconds or until the ignition key is turned on.

Remote-Controlled Trunk Release Capability

If you have the optional Trunk Release installed, simply press the remote control TRUNK button for 1-2 seconds to activate your vehicle electronic trunk release. The trunk will "pop" open (may require an optional relay).

Remote-Controlled Accessory Output

This output allows you to add a remote-controlled optional accessory such as a window roll-up or fuel door release. To activate your optional accessory, see the "Programming Table for Remote Controls" on page 12.

Remote Engine Start - Safety and Counter-Theft



CAUTION: Be sure to read the "WARNING" bulletin on the inside cover of this manual **before** attempting to operate remote start.

Automatic Safety and Counter-Theft Features

Before remote starting your engine, the PrimeStart system will automatically perform a safety check to ensure the following conditions have been met:

- Brake pedal is not depressed.
- Engine and ignition are turned off.
- Hood is closed.

After remote starting your engine, the PrimeStart system will shut off the engine immediately if the ignition is OFF and any of the following occurs:

- The hood is opened.
- The engine RPM rises above preset level.
- The brake pedal is pressed.
- The remote control START button is pressed.
- The 20 or 30 minute programmable run time expired.

Visual Fault Indication

The PrimeStart has a built-in fault detection system that automatically scans all of the safety zones, prevents the system from remote starting and provides a visual indication if a fault is detected. The parking lights will flash 1 time if the hood is opened or 3 times if the brake pedal is depressed and will not allow the engine to start. If this occurs, bring your vehicle to your authorized Prime Security dealer for service.

Remote Engine Start - Operation

Your PrimeStart system will start your vehicle engine with a touch of a button on your AviGlo™ remote control. To also cool or warm the interior of your vehicle before you enter, set the climate control to your preference (heater, defrost or air conditioning) **before remote starting**. Set the fan to a medium speed (**not maximum**). Ensure the vehicle is in "Park" and the key is **not** in the ignition.

To Remote Start the Engine:

1. Press the remote control START button for 1-2 seconds, 10-15 minutes before you enter the vehicle (this will allow the climate control time to heat or cool the vehicle.) The parking lights will flash 2 times, the engine will start and the parking lights will remain on as a visual indication that the engine is running. PrimeStart will automatically lock the doors when the engine is remote started. If you have a diesel engine, the PrimeStart will be programmed to start 15 seconds after the parking lights flash 2 times. This will allow time for the glow plugs to heat up.
2. If the engine does not remote start, the PrimeStart system will attempt to start the engine two additional times.
3. If the vehicle is left unattended, the engine will run for 20 minutes and then shut off automatically. You can also program the system to run the engine for 30 minutes. (See the "Programming Table for System Features" on page 11.)

To Operate the Vehicle While Remote Started:

1. Press the remote control UNLOCK button for 1-2 seconds. The doors will unlock.
2. Enter the vehicle (do not touch the brake pedal), turn the ignition key to the "ON" position and then press the brake pedal. Pressing the brake pedal will shut off the remote start and parking lights but the engine will remain running.
3. You can now drive the vehicle.

To Shut Off Remote Start:

At any time while the engine is remote started, you can shut the engine off with the remote control by pressing the remote control START button for 1-2 seconds. The engine and parking lights will shut off.

User-Programmable Temperature-Controlled Starting



CAUTION: Do not activate Temperature-Controlled Starting while the vehicle is in an enclosed area.

The PrimeStart system can be programmed to automatically start the vehicle engine whenever the temperature inside the vehicle reaches or drops below the preprogrammed temperature level. The PrimeStart will monitor the air temperature every 2½ hours and will only start the engine during extreme cold temperatures. There are three temperature levels to choose from. (This feature is programmed OFF from the factory and must be programmed ON to operate. (See the "Programming Table for System Features" on page 11).

To Activate:

Press the remote control LOCK and START buttons at the same time. The parking lights will turn on for 3 seconds, shut off for 1 second and turn on for 3 seconds. This will be your visual indication that you have activated the Temperature-Controlled Starting feature.

When the temperature inside the vehicle reaches the preprogrammed temperature level, the parking lights will flash 2 times, the vehicle will start and the parking lights will turn on. The vehicle will run for 10 minutes and then shut off. This will allow the engine to warm up and charge the battery.

To Deactivate:

Press the remote control LOCK and START buttons at the same time for 1-2 seconds. The parking lights will turn on for 3 seconds and then turn off. This will be your visual indication that you have deactivated the Temperature-Controlled Starting feature.

NOTE: At any time, if the ignition key is turned on or the vehicle is remote started, the Temperature-Controlled Starting feature will deactivate.

Pit Stop Mode



CAUTION: Do not leave passengers or pets in the vehicle while the system is in Pit Stop Mode.

The Pit Stop Mode allows you to park the vehicle for short-term stops, remove the ignition key and leave the engine running.

To Activate:

1. While the vehicle engine is running with the ignition key turned on, press the remote control START button for 1-2 seconds. The parking lights will flash 2 times and then stay on. (Make sure the vehicle is in "Park" and set the emergency parking brake.)
2. Turn the ignition key off and the engine will stay running.
3. Remove the ignition key and remote control and exit the vehicle.
Remember to keep the ignition key and remote control in your possession.
4. Press the remote control LOCK button for 1-2 seconds to secure your vehicle.

To Deactivate:

1. When you return to the vehicle, press the remote control UNLOCK button for 1-2 seconds. The doors will unlock.
2. Enter the vehicle (do not touch the brake pedal), turn the ignition key to the "ON" position and then press the brake pedal. The parking lights will shut off and you will now be able to drive the vehicle.

Protected Valet Mode

You should place your system in Protected Valet Mode whenever your vehicle is being serviced by mechanics, car wash personnel or driven by valet parking attendants. While in the Protected Valet Mode, all remote starter functions are bypassed to prevent unauthorized or accidental operation. If a remote start is attempted, the parking lights will flash 4 times and the vehicle will not start. Remote controlled door lock/unlock and trunk release will still operate.

To Turn on Protected Valet Mode:

1. Turn the ignition key to the "ON" position or start the engine.
2. Flick the valet switch to the "ON" position.
3. The LED will turn on solid red to indicate the system is in the Protected Valet Mode.
4. Turn the ignition key to the "OFF" position.

To Turn off Protected Valet Mode:

1. Turn the ignition key to the "ON" position or start the engine.
2. Flick the valet switch to the "OFF" position.
3. The LED will turn off to indicate the system is no longer in the Protected Valet Mode.
4. Turn the ignition key to the "OFF" position.

User-Programmable Features

All PrimeStart system and remote control programmable features are accomplished by turning the ignition key on (or starting the engine) and flicking the valet switch on and off a preset number of times.

The PrimeStart also allows you to add new remote controls in one step, delete lost or stolen remote controls or rearrange the factory preset remote control functions.

1. Remove the system from Protected Valet Mode. Programming cannot be accessed while the system is in Protected Valet Mode indicated by the LED on solid red.
2. Select the feature you wish to program from the "Programming Table for System Features" or the "Programming Table for Remote Controls" on pages 11 and 12. *Note the number of beeps associated with that feature.*
3. Turn the ignition key to the "ON" position.
4. Within 10 seconds, begin flicking the valet switch on and off. The built-in piezo beeper will beep once each time you flick the switch on then off.
5. Continue flicking the switch on and off, counting the number of beeps.

NOTE: Stop when you reach the number of beeps associated with your chosen feature.

6. Follow the "Secondary Action." You will hear a number of beeps to confirm that you have changed the setting of that feature.
7. Turn the ignition key to the "OFF" position.
8. Repeat steps 1-7 for any other feature you wish to program.

Programming Table for System Features

Feature	Factory Setting	No. of Beeps	Secondary Action
Ignition-Controlled Door Lock/Unlock	On	6	Wait 3 seconds, the piezo beeper will beep once for OFF, twice for ON.
0 or 3 Second Delay for Ignition-Controlled Door Lock	0 Second	7	Wait 3 seconds, the piezo beeper will beep once for 3 seconds, twice for 0 seconds.
RPM Door Locking	OFF	8	Wait 3 seconds, the piezo beeper will beep once for OFF, twice for ON.
Passive Starter Disable	OFF	9	Wait 3 seconds, the piezo beeper will beep once for OFF, twice for ON.
Remote Lock Starter Disable	ON	10	Wait 3 seconds, the piezo beeper will beep once for OFF, twice for ON.
Remote Start Run Time 20 or 30 Minutes	20 Minutes	13	Wait 3 seconds, the piezo beeper will beep once for 30 minutes, twice for 20 minutes.
Temperature-Controlled Starting OFF or 5°F (-15°C)	OFF	15	Wait 3 seconds. The piezo beeper will beep once for OFF, twice for 5°F (-15°C).
Temperature-Controlled Starting -7°F (-20°C) or -22°F (-30°C)	—	16	Wait 3 seconds. The piezo beeper will beep once for -7°F (-20°C), twice for -22°F (-30°C).

Programming Table for Remote Controls

Feature	Factory Setting	# of Beeps	Secondary Action
Remote Door Lock/Panic	LOCK Button	17	Press the LOCK Button, the piezo beeper will beep 1 time.
Remote Door Unlock	UNLOCK Button	18	Press the UNLOCK Button, the piezo beeper will beep 2 times.
Remote Engine Start	START Button	19	Press the START Button, the piezo beeper will beep 3 times.
Remote Trunk Release	TRUNK Button	20	Press the TRUNK Button, the piezo beeper will beep 4 times.
Temperature Controlled Start Active/Inactive	LOCK + START Buttons	21	Press the LOCK + START Button, the piezo beeper will beep 5 times.
Remote Accessory Output (-)	LOCK + UNLOCK Buttons	22	Press the LOCK + UNLOCK Button, the piezo beeper will beep 6 times.
One-Step Remote Control Code Learning	LOCK Button	23	Press the LOCK Button, the piezo beeper will beep 1 time.
Instant Remote Control Code Deletion	—	24	Wait 3 seconds, the piezo beeper will beep twice, all codes are erased out of memory.

PrimeStart 450 Owner's Manual

