

5-button AS-RFD systems Quick Start User Guide (DS4/DS4+)

Thank you for purchasing this Autostart product. This Quick Start User Guide contains what you need to get started. Full user guide is available at www.autostart.ca/Downloads.aspx.

COMMANDS FOR THE REMOTES

	Locks the doors and arms the system (if configured)
	Unlocks the doors and disarms the system (if configured)
	Opens the trunk if button is pressed for more than 3 seconds
	Remote starts/stops the engine
f	Access to various advance features of the remote and the remote starter. (For more details, refer to the full owner's guide).

REMOTE STARTING YOUR VEHICLE

Press and release the  button. If you have a 2-way RF system, the remote will play a start melody few seconds after the start command is sent. This is to provide confirmation that the vehicle has been successfully remote started.

To deactivate if the engine is already running, Press and release the  button. The engine and parking lights turn off to confirm shutdown. If you have a 2-way RF system, the remote will notify with text, icon and tones.

Press and hold the  icon for at least 4 seconds to reset the programmed run time.

READY MODE (MANUAL TRANSMISSION CARS ONLY)

When installed into a manual transmission vehicle, the system requires that the Ready Mode is properly set when parking. If Ready Mode is not properly set or is defeated after being properly set, the system will not start the engine.

STEPS		STATUS
1	With the engine running, ensure that the gear is neutral position. Press the foot brake then set the parking brake and leave the engine running.	
2	Release the foot brake. As long as the engine is running there is no time limit to perform this step.	
3	Within 20 seconds of foot brake release, press the  button.	The parking lights flash 5x and the remote start activates the ignition outputs. The 2-way remote confirms by playing the On tones.
4	Turn off and remove the key from the ignition switch. *	The engine remains running.
5	Exit the vehicle, close all the doors and press the  button	The engine and parking lights turn off and after a few seconds, the 2-way remote confirms by playing the Off tones.

* For Push-to-Start cars, press the Push-to-Start (PTS) button twice to turn the ignition ON (some models do not require activating PTS Ignition). Please refer to your authorized Autostart dealer for more information.

Guide d'utilisation abrégé de systèmes AS-RFD à 5 boutons (DS4/DS4+)

Nous vous remercions d'avoir choisi ce produit Autostart. Ce guide d'utilisation abrégé contient ce que vous aurez besoin pour débiter. Le guide de l'utilisateur complet est disponible ici : www.autostart.ca/Downloads.aspx.

UTILISATION DE LA TÉLÉCOMMANDE

	Verrouille les portières et arme le système (si configuré)
	Déverrouille les portières et désarme le système (si configuré)
	Ouvre le coffre si enfoncé pendant plus de 4 secondes
	Fait démarrer/arrêter le moteur
f	Accès aux diverses fonctions avancées de la télécommande et du démarreur à distance. (Pour plus de détails, référez-vous au guide de l'utilisateur complet).

DÉMARRER VOTRE VÉHICULE À DISTANCE

Appuyez et relâchez la touche . Si vous avez un système bidirectionnel, la télécommande émettra la mélodie de démarrage après la commande de démarrage envoyée. Le système démarrera le véhicule.

Pour désactiver lorsque le moteur est déjà en marche, Appuyez et relâchez la touche . Le moteur et les feux de stationnement s'éteindront, Si vous avez un système bidirectionnel, la télécommande affichera une alerte par texte, icône et sons.

Appuyer et maintenir  pendant au moins 4 secondes pour réinitialiser la durée d'exécution programmée.

MODE PRÊT (TRANSMISSION MANUEL SEULEMENT)

Lorsque le système est installé dans un véhicule à transmission manuelle, le système nécessite que le mode Prêt soit correctement configuré lors du stationnement du véhicule. Si le mode Prêt n'est pas correctement configuré ou est défectueux après avoir été correctement configuré, le système ne démarre pas le moteur.

ÉTAPES		STATUT
1	Pendant que le moteur est en marche, assurez-vous que toutes les portières, le capot et le coffre sont fermés et que le levier de vitesse est en position neutre.	
2	Appuyez et tenir enfoncé la pédale de frein puis engagez le frein de stationnement puis relâchez la pédale de frein.	
3	En 20 sec. ou moins, appuyez sur la touche  de la télécommande.	Les feux de stationnement clignoteront 5 fois rapidement et resteront allumés. La télécommande bidirectionnelle émettra la mélodie de démarrage.
4	Couper le contact et retirer la clé. *	Le moteur est toujours en marche.
5	Sortir du véhicule, fermer toutes les portières et appuyez sur la touche  .	Les feux de stationnement s'éteindront puis quelques seconds après, la télécommande affichera une alerte par texte, icône et sons.

* Pour les modèles avec allumage à bouton poussoir (PTS), appuyez deux fois sur le bouton poussoir (PTS) pour activer l'allumage (certains modèles ne nécessitent pas l'activation de l'allumage du bouton poussoir). Consultez votre détaillant Autostart pour plus de détails.