

# VIPER<sup>®</sup>home

## 501C Window/Door Sensor Quick Reference Guide

Congratulations on the purchase of your Viper Home Security Accessory. This guide walks you through the process of adding this accessory to your system and for mounting your accessory.

**Note:** Make sure you already have a Viper Home Starter kit or Viper Home Hub installed. Please refer to the quick reference guides found in these systems, or visit: [www.viper.com/home/support](http://www.viper.com/home/support).


1. Log into your Viper Home account at:  
[home.viper.com](http://home.viper.com)
2. To pair the Window/Door sensor to your system:  
Click on the "Devices" tab  
Click "Add New Device"  
Click "Add Window/Door sensor"
3. You are then prompted to insert the batteries provided within three minutes. Use a coin to pry open the sensor and insert the one AA battery provided.
4. Once the batteries are inserted the system automatically connects and confirms the Window/



- Door sensor is paired with your system.
5. After the sensor is paired, you can give it a unique name (i.e. "Front Door")  
In this screen, if you click the "More" button, you can set up additional options for the device, such as "arm stay", or "custom arm", as well as select what action the sensor performs when triggered.
  6. Once completed, click the "Finish" button.  
The sensor is now ready for mounting.

## ***Mounting instructions:***

1. Mount the larger part of the sensor (Magnetic Detector) on the frame side of the door or window that the sensor is to be used with.
2. Mount the smaller part of the sensor (the Magnet) on the door or window surface opposite the Magnetic Detector.
3. Makes sure the alignment marks (small dots) on the sensor are facing each other. The two parts of the sensor should not be more than  $\frac{3}{4}$ " apart.
4. The sensor should be mounted high and out of reach on either the door or window being used.



## ***Additional Information***

**Further information** – For additional support, including additional information videos and installation tips, visit: [www.viper.com/home/support](http://www.viper.com/home/support)

**Warranty Information** - Your system comes with a one year warranty. For complete warranty details visit: [www.viper.com/home/support](http://www.viper.com/home/support)



This device is intended for indoor use only and should not be mounted in any outside areas. Mounting the device outside will void the warranty.

**FCC/ID Notice:** This device complies with Part 15 of FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**CAUTION!** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

# DIRECTED®

Directed is committed to delivering world class quality products and services that excite and delight our customers.

Vista, CA 92081  
[www.viper.com](http://www.viper.com)

IG501C 2013-09

© 2013 Directed. All rights reserved.