

# VIPER<sup>®</sup>home

## 504S Indoor Siren Quick Reference Guide

Congratulations on the purchase of your Viper Home Security Accessory. This guide walks you through the process of adding this accessory to your system and for mounting your accessory.

**Note:** Make sure you already have a Viper Home Starter kit or Viper Home Hub installed. Please refer to the quick reference guides found in these systems, or visit: [www.viper.com/home/support](http://www.viper.com/home/support).

1. Log into your Viper Home account at:  
[home.viper.com](http://home.viper.com)
2. To pair the siren to your system:  
Click on the "Devices" tab  
Click "Add New Device"  
Click "Add Siren"
3. You are then prompted to insert the batteries provided within three minutes. First, remove the mounting piece/battery cover on the back of the siren, and install the AA batteries provided.
4. Once the batteries are inserted the system automatically connects and confirms the siren is paired with your system.
5. After the siren is paired, you can give it a



- unique name (i.e. "Hallway")
- Once completed, click the "Finish" button. The siren is now ready for mounting.

## ***Mounting instructions:***

- Mount the siren in a location where it will be heard and act as a deterrent to potential intruders.
- A good location to mount the siren is near your doorbell ringer or near an area that is considered a potential access point by an intruder.
- Once you have chosen the desired mounting location, remove the backing from the tape on the battery cover and mount the device. Alternatively, you can also mount the device with standard dry wall screws by screwing the mounting piece directly to the wall through the circular dimples on the mounting piece.



## ***Additional Information***

**Further information** – For additional support, including additional information videos and installation tips, visit: [www.viper.com/home/support](http://www.viper.com/home/support)

**Warranty Information** - Your system comes with a one year warranty. For complete warranty details visit: [www.viper.com/home/support](http://www.viper.com/home/support)



This device is intended for indoor use only and should not be mounted in any outside areas. Mounting the device outside will void the warranty.

**FCC/ID Notice:** This device complies with Part 15 of FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**CAUTION!** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

# DIRECTED.

Directed is committed to delivering world class quality products and services that excite and delight our customers.

Vista, CA 92081  
[www.viper.com](http://www.viper.com)

IG504S 2013-09

© 2013 Directed. All rights reserved.