

# VIPER<sup>®</sup>home

## 7250R Remote Control Quick Reference Guide

Congratulations on the purchase of your Viper Home Security Accessory. This guide walks you through the process of adding this accessory to your system.

**Note:** Make sure you already have a Viper Home Starter kit or Viper Home Hub installed. Please refer to the quick reference guides found in these systems, or visit: [www.viper.com/home/support](http://www.viper.com/home/support).

1. Log into your Viper Home account at:  
[home.viper.com](http://home.viper.com)
2. To pair the remote control to your system:  
Click on the "Devices" tab  
Click "Add New Device"  
Click "Add Key Fob"
3. You need to assign an account user to this remote. Click the "Browse" button and select the desired user for the remote control.
4. You are then prompted to insert the batteries provided within three minutes. Using a coin, remove battery cover on the back of the remote control, and install the CR2450 battery provided.



5. Once the battery is inserted the system automatically connects and confirms the remote control is paired with your system. If the remote does not connect when the battery is installed, remove the battery and press any button on the remote a few times and then repeat the pair process.
6. Once completed, click the "Finish" button. The remote control is now ready for use.

## ***Remote Control:***



Arms the system in arm away status.



Disarms the system.




Arms the system in the arm stay status.



Arms the system in the arm custom status.



(SOS) – When these buttons are pressed

together (system must be armed) a panic alert is sent to all users, and if a siren is installed with the system, the siren sounds. Panic can be stopped by pressing the  button, but this only stops the siren sound (as the notifications will have already been sent).



– this button shows the status of the security system by lighting the specific button on the remote control (arm, disarm, arm away, custom arm).

## ***Additional Information***

**Further information** – For additional support, including additional information videos and installation tips, visit: [www.viper.com/home/support](http://www.viper.com/home/support)

**Warranty Information** - Your system comes with a one year warranty. For complete warranty details visit: [www.viper.com/home/support](http://www.viper.com/home/support)

**FCC/ID Notice:** This device complies with Part 15 of FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**CAUTION!** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

# DIRECTED®

Directed is committed to delivering world class quality products and services that excite and delight our customers.

Vista, CA 92081  
[www.viper.com](http://www.viper.com)

OG7250V 2013-09

© 2013 Directed. All rights reserved.